

Armadillo Fastener Quick Reference Guide

| Standard Fasteners for Deck Boards | | | | | | | |
|--|------------------------------|---------------|------------------|-------------|------|---------------|-----------------|
| Manufacture | Brand name | Fastener Size | Do Not Recommend | Recommended | | Fastener Size | Pilot Hole Size |
| | | | | Good | Best | | |
| Camo | Edge Deck Screws | #7 X 1-7/8" | X | | | #7 | 1/8" |
| Camo | Edge Deck Screws | #7 X 1-7/8" | X | | | #8 | 1/8" |
| DeckMate | Star Drive Coated Screw | #8 X 2" | X | | | #8 | 1/8" |
| Grip Fast | Stainless Steel Deck Screw | #8 X 2" | X | | | #8 | 1/8" |
| DeckMate | Star Drive Coated Screw | #9 X 2" | X | | | #9 | 5/32" |
| DeckMate | Star Drive Coated Screw | #9 X 2-1/2" | X | | | #9 | 5/32" |
| Grip Fast | Triple Coated Deck Screws | #9 X 2-1/2" | X | | | #9 | 5/32" |
| GRK Fasteners | RT Composite Trim Head Screw | #8 X 2-1/2" | | X | | #8 | 1/8" |
| Grip Fast | Composite Cladding Screw | #9 X 2" | | | X | #9 | 5/32" |
| DeckMate | Star Drive Composite Screws | #9 X 2-1/2" | | X | | #9 | 5/32" |
| Grip Rite | Composite Deck Screw II | #9 X 2-1/2" | | | X | #9 | 5/32" |
| Grip Rite | Composite Deck Screw II | #9 X 3 | | X | | #9 | 5/32" |
| Starborn | Cap-Tor xd Headcote 316 | #10 X 2-1/2" | | | X | #10 | 9/64" |
| Starborn | Cap-Tor xd Headcote 316 | #10 X 2-3/4" | | | X | #10 | 9/64" |
| Grip Fast | Composite Decking Screws | #10 X 2-3/4" | | | X | #10 | 9/64" |
| <p>Note: A pilot hole must be drilled prior to installing any fastener in the Armadillo boards whether or not the fastener company recommends pre-drilling.</p> | | | | | | | |

| Standard Fasteners for Fascia Boards | | | | | | | |
|--|---|---------------|------------------|-------------|------|---------------|-----------------|
| Manufacture | Brand name | Fastener Size | Do Not Recommend | Recommended | | Fastener Size | Pilot Hole Size |
| | | | | Good | Best | | |
| Grip Fast | Ultra Clip Hidden Fastener System Decking Screw | #6 X 1-1/2" | | X | | #6 | 3/32" |
| Grip Rite | Trim Screws | #7 X 1-5/8" | | X | | #7 | 1/8" |
| DeckMate | Star Drive Composite Screws | #8 X 1-5/8" | | | X | #8 | 1/8" |
| Grip Rite | Composite Deck Screw II | #8 X 1-5/8" | | | X | #8 | 1/8" |
| DeckMate | Star Drive Coated Screw | #8 X 1-5/8" | | | X | #8 | 1/8" |
| Grip Fast | Stainless Steel Deck Screw | #8 X 1-5/8" | | | X | #8 | 1/8" |
| <p>Note: A "pilot" hole must be drilled prior to installing any fastener in the Armadillo fascia whether or not the fastener company recommends pre-drilling.</p> | | | | | | | |